


Product Information

Periphery module

PM RTD802



(valid from 06/2012)

Changes to older versions of this document

Changed in Rev. 06: broken wire information added: only at 2 wire use!
Changed in Rev. 07: temperature areas, connectors, new design line
Changed in Rev. 08: Information for disposal of old equipment

Description

compact peripheral module for

- 8 analog inputs to be configured by software

Temperature:
 PT100,
 PT1000,
 NI100,
 NI1000,
 KTY81-1xx
 Resistivity survey
 200Ω ,
 2kΩ
 Voltage:
 0 .. 400mV,
 0 .. 1V

2 analog outputs (0,5 ...10V)

- Resolution 12 Bit
- green diagnostic LED for each input
 - LED 1 for AI0
 - LED 2 for AI1
 - LED 3 for AI2
 - ...
 - LED 8 for AI7
- red diagnostic LED for each input for error (sensor-/ broken wire detection)
 - LED 1 for AI0
 - LED 2 for AI1
 - LED 3 for AI2
 - ...
 - LED 8 for AI7
- insertion stripe with description field for every signal
- cage-clamp connector with bolt flanges on side

for 2-wire RTDs





Figure above: Description and wiring of all connections of peripheral module RT802 with 2-wire RTDs



above: block diagram of RTD802 for 2-wire RTDs

Input	
Start address:	128
End address:	143
Channel	Address
Channel 1:	128
Channel 2:	130
Channel 3:	132
Channel 4:	134
Channel 5:	136
Channel 6:	138
Channel 7:	140
Channel 8:	142
Output	
Start address:	128
End address:	131

above: configuration block of start-/ end addresses of RTD802-i/o's (in words) in the ConfigStage

Description

compact peripheral module for

- 8 analog inputs to be configured by software

Temperature:
PT100,
PT1000,
NI100,
NI1000,
KTY81-1xx
Resistivity survey
200Ω ,
2kΩ
Voltage:
0 .. 400mV,
0 .. 1V

2 analog outputs
(0,5 ...10V)

- Resolution 12 Bit
- green diagnostic LED for each input
 - LED 1 for AI0
 - LED 2 for AI1
 - LED 3 for AI2
 - ...
 - LED 8 for AI7
- red diagnostic LED for each input for error (sensor-/ broken wire detection)
 - LED 1 for AI0
 - LED 2 for AI1
 - LED 3 for AI2
 - ...
 - LED 8 for AI7
- insertion stripe with description field for every signal
- cage-clamp connector with bolt flanges on side

for 3-wire RTDs





Figure above: Description and wiring of all connections of peripheral module RT802 with 3-wire RTDs



above: block diagram of RTD802 for 3-wire RTDs

Input		
Start address:	128	
End address:	143	
Channel	Address	Type
Channel 1:	128	PT100 (3-wire)
Channel 2:	130	PT100 (2-wire)
Channel 3:	132	PT100 (3-wire)
Channel 4:	134	PT100 (4-wire)
Channel 5:	136	PT1000 (2-wire)
Channel 6:	138	PT100 (2-wire)
Channel 7:	140	PT100 (2-wire)
Channel 8:	142	PT100 (2-wire)
Output		
Start address:	128	
End address:	131	

above: configuration block of start-/ end addresses of RTD802-i/o's (in words) in the ConfigStage

Description

compact peripheral module for

- 8 analog inputs to be configured by software

- Temperature:
 - PT100,
 - PT1000,
 - NI100,
 - NI1000,
 - KTY81-1xx
- Resistivity survey
 - 200Ω ,
 - 2kΩ
- Voltage:
 - 0 .. 400mV,
 - 0 .. 1V

2 analog outputs
(0,5 ...10V)

- Resolution 12 Bit
- green diagnostic LED for each input
 - LED 1 for AI0
 - LED 2 for AI1
 - LED 3 for AI2
 - ...
 - LED 8 for AI7
- red diagnostic LED for each input for error (sensor-/ broken wire detection)
 - LED 1 for AI0
 - LED 2 for AI1
 - LED 3 for AI2
 - ...
 - LED 8 for AI7
- insertion stripe with description field for every signal
- cage-clamp connector with bolt flanges on side

for 4-wire RTDs






Figure above: Description and wiring of all connections of peripheral module RTD802 with 4-wire RTDs



above: block diagram of RTD802 for 4-wire RTDs



above: configuration block of start-/ end addresses of RTD802-i/o's (in words) in the ConfigStage

Description

compact peripheral module for

- 8 analog inputs to be configured by software

Temperature:
 PT100,
 PT1000,
 NI100,
 NI1000,
 KTY81-1xx
 Resistivity survey
 200Ω ,
 2kΩ
 Voltage:
 0 .. 400mV,
 0 .. 1V

2 analog outputs (0,5 ... 10V)

- Resolution 12 Bit
- green diagnostic LED for each input
 - LED 1 for AI0
 - LED 2 for AI1
 - LED 3 for AI2
 - ...
 - LED 8 for AI7
- red diagnostic LED for each input for error (sensor-/ broken wire detection)
 - LED 1 for AI0
 - LED 2 for AI1
 - LED 3 for AI2
 - ...
 - LED 8 for AI7
- insertion stripe with description field for every signal
- cage-clamp connector with bolt flanges on side

for voltage measurement





Figure above: Description and wiring of all connections of PM RT802 for voltage measurement



above: block diagram of RTD802 for voltage measurement

Input		
Start address:	128	
End address:	143	
Channel	Address	Type
Channel 1:	128	PT100 (4-wire)
Channel 2:	130	0..300 Ohm (3-wire)
Channel 3:	132	0..300 Ohm (4-wire)
Channel 4:	134	0..2k Ohm (2-wire)
Channel 5:	136	0..2k Ohm (3-wire)
Channel 6:	138	0..2k Ohm (4-wire)
Channel 7:	140	0..400mV
Channel 8:	142	0..1V
Channel 9:	144	Not available
Output		
Start address:	128	
End address:	131	

above: configuration block of start-/ end addresses of RTD802-i/o's (in words) in the ConfigStage

Technical data			
Operating temperature range Storage temperature range Dimensions W x H x D (mm) Weight	-20°C ... +60°C (without condens.) -30°C ... +80°C 20 x 108 x 70 mm ca. 150 g	Load voltage L+ Current consumption Power dissipation	24V DC (10V ... 30V DC, connected by device supply) 50 mA (max.) 1,2 W (max.)
Connection technology	unlockable connector with bolt langes on side (cage clamp technology) for cross section up to max. 1,5mm ²	Wire length unshielded (max.) shielded (max.)	30 m 100 m
Analog inputs	8	valid voltage between inputs and A-GND (max.)	0 V ... +24 V DC
Diagnostic LEDs	8 green: signal in valid area 8 rot: short circuit no displaying broken wires and open inputs	Error message during override metering area	adjustable diagnosis- and limit value alert on request
Input area (nominal values)	PT100: -50°C ... 600°C PT1000: -50°C ... 250°C Ni100: -50°C ... 250°C Ni1000: -50°C ... 150°C KTY81/1xx: -50°C ... 150°C 0 ... 300 Ω, 0... 2 kΩ	Override area (LEDs off)	PT100: >600°C ... 620°C PT1000: >250°C ... 300°C Ni100: >250°C ... 275°C Ni1000: >150°C ... 175°C KTY81/1xx: >125°C ... 150°C >300 Ω ... 325 Ω, >2 kΩ ... 2,1 kΩ
Value number format	0,1°C for temperature metering area, 0,1° Ω for resistor metering area, 0000 ... 6C00 (hexadecimal) for voltage metering area	Underride area (red LED on)	PT100: -200°C ... < -50°C PT1000: -200°C ... < -50°C Ni100: -200°C ... < -50°C Ni1000: -200°C ... < -50°C KTY81/1xx: -75°C ... < -50°C
Input resistance	500 Ω (typ.) metering area PT100	Access of sensor	2- or 4- wire, symmetric
Resolution	12 Bit		
Metering pricniple / conversion principle	successive approximation	Broken wire detection	by overrun, shortfall of metering area (only at 2 wire use!)
Sampling cycle time = Integration time	adjustable 1ms ... 35767 ms default: 100 ms (=Net frequency filter 50Hz + 60Hz)	Specifyity (based on input area)	< 1%
Analog outputs	2	Value number format	0000 ... 6C00 (hexadecimal)
Output area (nominal values)	0,5 ... 10V	Short cut protection	yes
Override area	0 ... 11V	Short cut current (typ.)	32 mA
Resolution	12 Bit	Setting time:	response time τ (typ) 1,5 ms
Load resistance against A-GND	1kΩ (max.)	Specifyity (based on output area)	< 1%

Ordering data module

Identification	Order-no.	Packaging unit
Periphery module RTD8O2	PM-RTD8O2-02	PU: 1 piece
Connector 2x10pin with pin markings and bolt flanges on side	E-CONS20A-00	PU: 1 piece

Qualified personnel

All devices described in this manual may only be used, built up and operated together with this documentation. Installation, initiation and operation of these devices might only be done by instructed personnel with certified skills, who can prove their ability to install and initiate electrical and mechanical devices, systems and current circuits in a generally accepted and admitted standard.

Manuals, sample programs

Additional documentation by manuals is available as well sample applications at the download area of www.insevis.com in English language for free download.

Copyright

This and all other documentation and software, supplied or hosted on INSEVIS web sites to download are copyrighted. Any duplicating of these data in any way without express approval by INSEVIS GmbH is not permitted. All property and copy rights of these documentation and software and every copy of it are reserved to INSEVIS GmbH.

Trade Marks

INSEVIS refers that all trade marks of particular companies used in own documentation are reserved trade marks are property of the particular owners and are subjected to common protection of trade marks.

Disclaimer

All technical details in this documentation were created by INSEVIS with highest diligence. Anyhow mistakes could not be excluded, so no responsibility is taken by INSEVIS for the complete correctness of this information. This documentation will reviewed regularly and necessary corrections will be done in next version. With publication of this data all other versions are no longer valid.

Disposal



Do not throw old appliances in the household waste! In the interest of environmental protection, old appliances must be collected separately from unsorted municipal waste. You can find out more about the proper disposal / return of your old appliance at www.insevis.com/disposal.

Attention: The deletion of personal data on the old devices to be disposed of is the responsibility of the end user.

With publication of this information all other versions are no longer valid.